

# Installing Your Handrail



- 1.) Place the handrail in situ on the wall & then mark the position of your first hole (please note that standard height for handrails is 900mm above ground level)
- 2.) Drill the hole intended for fixing using a 8mm  $\emptyset$  masonry drill bit
- 3.) Insert the rawl-plug into the drilled hole
- 4.) Secure the handrail with a screw (provided), using a phillips (PZ2) screwdriver bit
- 5.) Repeat the above steps to secure the remaining brackets

**Screw specs:** Load bearing, galvanised 7.5mm  $\emptyset$  x 70mm screws (phillips PZ2 insert bit) to be used in conjunction with 8mm  $\emptyset$  masonry drill bit & 8mm  $\emptyset$  x 40mm rawl plugs.

Please note that the screws provided are standardised fixings intended for fixing to a concrete base or solid brick wall. As such, certain surfaces will require special means for fixing. If in doubt please consult a professional. The Handrail People shall not accept responsibility where the product fails to be secured in a proper manner and without the proper means of fixation.

If you have any concerns or problems, please don't hesitate to contact us for help or advice.